
OTIS

"M" = MAIN

"R" = REMOTE

Ver. 1 Rel. 06/01/04



Power Supply Studs Placement

DRIVER OPTIONS:
USE OEMS-X ONLY IF 411 SYSTEM IS USING THE EMS OPTION