

|         | BINARY FLOOR CHART |         | BINARY BITS                              |
|---------|--------------------|---------|--|
| 1000000 |                    |         | 48 A A A A A A A A A A A A A A A A A A A |
| 0111111 | 0101111            | 0011111 | 0001111                                  |
| 0111110 | 0101110            | 0011110 | 0001110                                  |
| 0111101 | 0101101            | 0011101 | 0001101                                  |
| 0111100 | 0101100            | 0011100 | 0001100                                  |
| 0111011 | 0101011            | 0011011 | 0001011                                  |
| 0111010 | 0101010            | 0011010 | 0001010                                  |
| 0111001 | 0101001            | 0011001 | 0001001                                  |
| 0111000 | 0101000            | 0011000 | 0001000                                  |
| 0110111 | 0100111            | 0010111 | 0000111                                  |
| 0110110 | 0100110            | 0010110 | 0000110                                  |
| 0110101 | 0100101            | 0010101 | 0000101                                  |
| 0110100 | 0100100            | 0010100 | 0000100                                  |
| 0110011 | 0100011            | 0010011 | 0000011                                  |
| 0110010 | 0100010            | 0010010 | 0000010                                  |
| 0110001 | 0100001            | 0010001 | 0000001                                  |
| 0110000 | 0100000            | 0010000 | 0000000                                  |

## **INSTALLATION GUIDE**

- 1. MAKE SURE THE INPUT RESISTORS ARE FULLY SEATED IN THEIR SOCKETS.
- 2. CONNECT 115VAC TO THE OUTER TERMINALS OF CONNECTOR J1. THE CENTER TERMINAL HAS NO CONNECTION.
- 3. SHORT THE TWO PINS OF S2 (TEST JACK) TOGETHER. THE DISPLAY WILL CYCLE THROUGH THE FLOOR DATA. THIS SHOWS WHAT FLOOR MARKINGS WILL BE DISPLAYED AND ALLOWS ADJUSTMENT OF THE SCROLL RATE AND OPTIONAL PASSING CHIME VOLUME.
- 4. MAKE SURE THE SIGNAL CABLE(S) IS PLUGGED INTO THE DRIVER BOARD CORRECTLY.
- 5. CONNECT THE SIGNAL CABLE(S) TO THE CONTROLLER. THE VOLTAGE AND DC POLARITY ARE MARKED ON THE REVERSE SIDE. THE UNIT WORKS LIKE A LIGHT BULB; IT NEEDS VOLTAGE FROM COMMON TO THE SELECTED INPUT.
- 6. IF THE INPUT IS DC AND YOU SUSPECT THE POLARITY IS WRONG, PUT THE SELECTED FLOOR WIRE TO COMMON AND COMMON TO THE SELECTED FLOOR INPUT. IF THE UNIT DISPLAYS THE FLOOR, CONTACT TECH SUPPORT.
- 7. IF THE INPUT FORMAT IS SINGLE LINE PER FLOOR, ONLY ONE WIRE SHOULD HAVE VOLTAGE PRESENT (WITH REFERENCE TO COMMON) AT ANY TIME.
- 8. IF THE UNIT DOES NOT SEEM TO WORK PROPERLY, RECHECK THE ABOVE STEPS. IF THE PROBLEM CONTINUES, RECORD THE SERIAL NUMBER FROM THE WHITE LABEL ON THE UNIT AND EXACTLY WHAT THE UNIT DISPLAYS AT EACH FLOOR, THEN CONTACT TECH SUPPORT AT 419-636-6705.

| DATE DRAWN:<br>04/24/07                      | DRAWN BY:          | REQUESTED BY: | C.E. ELECTRONICS, IN   | ıc   |
|--|--------------------|---------------|--|------|
| BOARD NUMBER:<br>N/A                         | LAST DATE REVISED: | APPROVED BY:  | 2107 Industrial Drive<br>Bryan, Ohio 43506<br>(419) 636-6705 |      |
| PRODUCT COMPETITOR SERIES BINARY FLOOR CHART |                    |               | DWG. NO. COMP_BINCHART_TJ                                    | REV: |