



LED FUNCTIONS DURING NORMAL OPERATION			
YELLOW*	GREEN	RED	CONDITION
☀	☀	○	BATTERY PACK IS FULLY CHARGED AND CCU BOX IS CONNECTED. BATTERY PACK IS NOT IN SERVICE.
☀	○	☀	BATTERY PACK IS CHARGING. BATTERY PACK IS NOT IN SERVICE.
☀	○	○	MONITORED AC LOSS WAS DETECTED. BATTERY PACK SWITCHED INTO SERVICE AND BATTERY BACKUP IS ACTIVE.
⚡ (FLASHING)	○	○	LOW BATTERY VOLTAGE

☀ - LED LIT  
○ - LED OFF

\* - YELLOW LED IS ONLY LIT IF THE CABLE FROM THE CCU IS CONNECTED AND THE CCU IS TURNED ON.

NOTE: THE BATTERY BRACKET SHOULD NOT BE USED TO SUPPORT THE WEIGHT OF THE BATTERIES. MOUNT THE BOX FLAT OR WITH THE BATTERIES AT THE BOTTOM AS SHOWN ABOVE.

JOB# \_\_\_\_\_

BOARD VERSION CE2196 \_\_\_\_\_

**MBATT / MBATT-E**

DATE DRAWN: 05/26/09	DRAWN BY: DAC	REQUESTED BY: DV	 C.E. ELECTRONICS, INC. 2107 Industrial Drive Bryan, Ohio 43506 (419) 636-6705
BOARD NUMBER: 2196	LAST DATE REVISED: -	APPROVED BY:	
PRODUCT MICRO COMM BATTERY BACKUP			DWG. NO. MBATT_01
			REV. -