


## SEC01-XXXX SECURITY ACCESS SYSTEM INFORMATION

DIP	OFF	NORMAL OPERATING MODE
1	ON	SELF-TEST MODE
DIP	OFF	TRI-COLOR LED INDICATOR
2	ON	16-CHARACTER VF DISPLAY
DIP	OFF	NOT USED
3	ON	SHOULD REMAIN OFF
DIP	OFF	INSERTION-TYPE CARD READER
4	ON	SWIPE-TYPE CARD OR PROXIMITY READER

DIP 8	DIP 7	DIP 6	DIP 5	LANDING NUMBER
OFF	OFF	OFF	OFF	1
OFF	OFF	OFF	ON	2
OFF	OFF	ON	OFF	3
OFF	OFF	ON	ON	4
OFF	ON	OFF	OFF	5
OFF	ON	OFF	ON	6
OFF	ON	ON	OFF	7
OFF	ON	ON	ON	8
ON	OFF	OFF	OFF	9
ON	OFF	OFF	ON	10
ON	OFF	ON	OFF	11
ON	OFF	ON	ON	12
ON	ON	OFF	OFF	13
ON	ON	OFF	ON	14
ON	ON	ON	OFF	15
ON	ON	ON	ON	16

## NOTES:

- 1 <u>On SEC01-RXXX units ONLY.</u> Use 18 AWG or larger wire to connect power (V+ and COM) to the unit.
- Connect using three 24 AWG shielded, twisted pair wires. One wire of the SIGCOM pair will not be used.
- 3 If communication problems occur during programming, call Tech Support at 419-636-6705 for instructions on installing termination resistors.



DATE DRAWN: 08/04/99	DRAWN BY: KLS	REQUESTED BY: JP, TE	6	C.E. ELECTRONICS, I 2107 Industrial Drive	NC.
BOARD NUMBER: 2463	LAST DATE REVISED: 01/18/18	APPROVED BY:	<u> </u> @	Bryan, OH 43506 (419) 636-6705	
PRODUCT SEC01 SECU	IRE ACCESS SYSTEM	DWG. NO.	SEC01004	REV F	